



All parts and J1 connections should be at the top side.
 Sensor should be at bottom side, with angled marks of sensor pointing towards T1.
 J1 point 1 is square island.

Sheet: /
 File: GCA173_wheel_counter.kicad_sch

Title:

Size: A4
 KiCad E.D.A. 8.0.3

Date:

Rev:
 Id: 1/1