

Qty	Reference	Part
1	R1	47 KOhm
1	R2	100 KOhm
2	R3,R4	470 Ohm
1	R5 *)	100 Ohm 2Watt
1	C1	ELCO 100 uF 16V rad
1	C2	ELCO 10 uF 16V rad
2	C3,C4	100 nF
1	C5	ELCO 2,2 uF 16V rad
1	VR1	7805 TO220
1	U1	PIC18F2480 with socket DIL28s
1	U2	MCP2551 with socket DIL8
1	Le1	LED 3mm green
1	Le2	LED 3mm red
2	LCD1	WSL14G (www.reichelt.de)
1	Res1	RESONATOR 4MHz
1	J1	D-SUB BU 09EU
1	J2	D-SUB ST 09EU
1	J3	PSS254/02
1	J4 *)	PSS254/02
1	Pot1	PSS254/03 for connection Potmeter
1	Pot2 *)	adjust pot 10K
18	S1..S18	BUTTON i.e. Taster 3301B (www.reichelt.de)
2	flatcable conn.	PFL14 (www.reichelt.de)
1	Flatcable 14 wire	AWG28-14G 3M (www.reichelt.de)
1	bolt and nut 3mm	
1	Pcboard	CAN-GC5

*) See manual on <http://wiki.rocrail.net/doku.php?id=can-gca5-en>

Fastening material for PCBoard and display are not included.